



## Office & Showroom

Shanghai  
Tel: (86) 21 6278 8888

Beijing  
Tel: (86) 10 8521 7588

Guangzhou  
Tel: (86) 20 3892 2422

Shenzhen  
Tel: (86) 769 8203 1111 ext 31300

Dongguan  
Tel: (86) 769 8203 1111

Hong Kong  
Tel: (852) 2828 6888

HNI Singapore  
Tel: (65) 6817 8750

## 分行及展厅

上海  
电话：(86) 21 6278 8888

北京  
电话：(86) 10 8521 7588

广州  
电话：(86) 20 3892 2422

深圳  
电话：(86) 769 8203 1111 ext 31300

东莞  
电话：(86) 769 8203 1111


香港  
电话：(852) 2828 6888

## Service Hotline

Mainland China: (86) 800 820 6073  
Hong Kong & Asia Pacific:  
(852) 2828 6000

## 客户服务热线

中国大陆：(86) 800 820 6073  
香港及亚太区：(852) 2828 6000




Ease



INSTRUCTION





# Ease: The Perfect Fit

跃想：贴身之选



## a Armrest Adjustment

Push the arm trigger to adjust the height, and release to lock the arm to desired position. Push or pull the armrest forward or backward to adjust according to your forearm position.

### 扶手调节

要调节扶手的高度，可按压扶手下方的按钮调节至合适您手臂摆放的高度位置，然后松开便可。此外，可将扶手往前后方移动以适合您的前臂摆放位置。



## b Seat Height

To raise the seat, lift your weight off the seat and pull up on the lever. To lower seat, lift up on the lever while you are seated. Release lever when seat reaches desired height.

### 座椅高度

要将座椅调节到所需的高度，可将身体离开椅座，向上拉动调节手柄让座椅升高；如需将座椅降低，可坐在椅座上，将手柄上拉便可随意让座椅降低。



## c Headrest Adjustment

The headrest can be adjusted forward or backward, to suit your desired neck position.

### 头枕

头枕可上下调节，调校至承托您颈部最舒适的位置。



## d Lumbar Support

Lumbar adjustment provides support for your back. Slide the backrest up or down to your desired position.

### 腰支撑

全面提供您脊椎及腰背的承托，腰支撑随您的不同需要上下调节，以舒减疲劳。



## e Tension Control

Turn the knob clockwise to increase tension, counterclockwise to reduce tension.

### 倾仰力度控制旋钮

顺时针或逆时针扭动倾仰力度调节旋钮，便可应您的需要增大或减小椅子的倾仰力度。



The ergonomic design of the Ease chair offers the most comfortable seating experience, providing you with healthier support throughout the entire working day.

具人体工学设计的跃想，为您带来最舒适的坐感体验，为您在繁忙的工作天提供充足健康的舒缓。